

# EDGE 2

## CONTROLLER UPDATE



### EDGE®2 UPDATE FEATURES

FEATURES		EDGE 2	EDGE
1	Screen	<ul style="list-style-type: none"> <li>• Capacitive screen functions like a smart phone. Swipe or slide from one screen to the other.</li> <li>• Reacts more quickly to touch.</li> </ul>	<ul style="list-style-type: none"> <li>• Resistive screen that needs to be pressed to operate.</li> </ul>
2	Icons/Navigation	<ul style="list-style-type: none"> <li>• Updated Icons</li> <li>• Main menu lists an overview of all rooms.</li> <li>• Select a room to gain access to the setting and operation page of that room.</li> <li>• Configuration Menu: Left to right.</li> </ul>	<ul style="list-style-type: none"> <li>• Static icons in upper left corner of display.</li> <li>• Configuration Menu: Top to bottom</li> </ul>
3	In Room/Tile Adjustment	<ul style="list-style-type: none"> <li>• Expandable tiles to see more details.</li> <li>• Fan and inlet status in one ventilation tile screen.</li> </ul>	NOT AVAILABLE
4	In Room/Ventilation Tile/Stages	<ul style="list-style-type: none"> <li>• CFM for each stage displayed in the grid and under the ventilation tile.</li> </ul>	NOT AVAILABLE
5	In Room/Tile Repositioning	<ul style="list-style-type: none"> <li>• Customizable room views</li> </ul>	NOT AVAILABLE
6	Room/Shortcut Key	<ul style="list-style-type: none"> <li>• Faster navigation from tile to tile (fewer clicks)</li> </ul>	NOT AVAILABLE
7	Light Program	<ul style="list-style-type: none"> <li>• Graphical view of the light schedule.</li> <li>• 3-day light schedule history.</li> <li>• Light program option shortcut key.</li> </ul>	NOT AVAILABLE
8	Alarms, Events & Issues	<ul style="list-style-type: none"> <li>• Customizable navigation sorting. (Alarms/Events/Issues)</li> <li>• Alarm acknowledge button.</li> </ul>	All in same page.
9	Ventilation Grid	<ul style="list-style-type: none"> <li>• Reordering of fan and inlet tiles. (One dot if fan is full ON.)</li> </ul>	<ul style="list-style-type: none"> <li>• Fans/Inlets are displayed in the order they were created. (Two dots if fan is full ON)</li> </ul>
10	Ventilation Grid	<ul style="list-style-type: none"> <li>• Fan stage started any day of the week</li> </ul>	NOT AVAILABLE
11	Scheduling/Wizard	<ul style="list-style-type: none"> <li>• Schedule started any day of the week.</li> <li>• Wizard setup for faster repeatable scheduling. (Example: A purge schedule in which every 30 minutes air is purged for 2 minutes.)</li> </ul>	NOT AVAILABLE
12	Programmable Timer	<ul style="list-style-type: none"> <li>• Can be programmed down to the second.</li> </ul>	<ul style="list-style-type: none"> <li>• Can be programmed to the minute only.</li> </ul>

## EDGE®2 UPDATE FEATURES CONTINUED...

FEATURES		EDGE 2	EDGE
<b>13</b>	<b>Outside Room Tile</b>	<ul style="list-style-type: none"> <li>Weather station and Bulk Feed Tank information found under the tile.</li> </ul>	NOT AVAILABLE
<b>14</b>	<b>Custom Units</b>	<ul style="list-style-type: none"> <li>Temperature: C/F</li> <li>Weight: Gram/Pounds</li> <li>Water: L/G</li> </ul>	NOT AVAILABLE
<b>15</b>	<b>Programs</b>	<ul style="list-style-type: none"> <li>Up to 8 programs can be set.</li> <li>Programs can be switched manually or by animal stage in version 4.2</li> </ul>	NOT AVAILABLE
<b>16</b>	<b>Natural Ventilation/ Wind Compensation</b>	<ul style="list-style-type: none"> <li>Wind compensation on individual panels with 4 steps of compensation.</li> </ul>	<ul style="list-style-type: none"> <li>Limited wind compensation in one direction for all panels.</li> </ul>
<b>17</b>	<b>Natural Ventilation/Purge with wind compensation</b>	<ul style="list-style-type: none"> <li>Purge with wind compensation is available in 4 steps depending on wind speed</li> </ul>	NOT AVAILABLE
<b>18</b>	<b>Heaters/Brooder/Natural Curtain Interlocking</b>	<ul style="list-style-type: none"> <li>Heaters can be forced off during purge cycles.</li> <li>Natural curtains can be forced to close or set for minimum for minimum opening during heating cycles.</li> </ul>	NOT AVAILABLE
<b>19</b>	<b>Maximum Ventilation</b>	<ul style="list-style-type: none"> <li>Version 4.2 - Set a maximum power stage and a maximum tunnel stage to block the ventilation under minimum animal age. (one for power, one for tunnel)</li> </ul>	NOT AVAILABLE



EDGE®2 supports all major languages and is UL/CSA certified and CE approved.

**Contact your AP representative  
 or visit [automatedproduction.com](http://automatedproduction.com)  
 for more information.**